



WATERPROOFING

# SOPRASEAL<sup>®</sup> STICK VP WALLS



## VAPOUR PERMEABLE AIR BARRIER MEMBRANE



SOPRASEAL STICK VP is a self-adhesive vapour-permeable air-barrier membrane with a tri-laminated polypropylene complex on its surface. Used in wall construction, it stands out due to its unmatched adhesive properties. Its width and self-adhesive underface, protected by a silicone release film, make it very easy to install. It can be used on most building surfaces, such as masonry, concrete, wood and gypsum.

- Better adhesive properties than competitive products
- No primer required
- UV exposure up to 180 days
- Self-sealing membrane ensuring continuous waterproofing

### SURFACE PREPARATION

The substrate must be clean, sound, free of excess of water and loose materials, grease and any contaminants, which may compromise the performance of the product.

### COMPLEMENTARY PRODUCT

#### 12-INCH NEOPRENE ROLLER

Maximizes SOPRASEAL STICK VP membrane adhesion.

#### SOPRASEAL STICK FLASHPRO SOPRASEAL STICK FLASHPRO HT

Ensure sealing of various openings.

SOPRASEAL STICK VP	
THICKNESS	0.6 mm (24 mil)
DIMENSIONS	0.95 x 30 m (37 in x 98 ft)
SURFACE	Tri-laminated polypropylene complex
UNDERFACE	Self-adhesive, covered with a silicone release film
WATER VAPOUR PERMEANCE (ASTM E96 - METHOD B)	972 ng/Pa·s·m <sup>2</sup> (17 perm)



## INSTALLATION INSTRUCTIONS

1



Peel off the top portion of the silicone release film and adhere the membrane to the substrate, making sure the membrane is well aligned.

2



Gradually peel off the remaining silicone release film, making sure the membrane adheres completely to avoid air pockets and wrinkles.

3



Use a roller to apply pressure over the entire surface of the membrane to ensure uniform adhesion to substrate.

4



Use a compatible sealant to seal around details, reverse laps and critical areas.

If you have any questions about this product or its installation, please contact your SOPREMA representative.

